

Foot Switches

With Latching Contacts

After initially pressing the pedal, the switch setting is retained even after the pedal is released. The contact is not interrupted before the pedal is pressed again (bistable).



Ordering Instructions for foot switches with latch-action switching

Foot switches with latch-action switching have “Y” in the article code and can be delivered in single and two pedal versions.

Single pedal foot switch F1				
Article number	Designation	Switching contacts		Special feature
		Pedal 1		
6161800247	F1-SU1Y UN	1NC / 1NO		Bistable Y, Prot. shroud UN
6161000676	F1-A2Y	2NC		Bistable Y
6061100001	F1-U1Y	1NC / 1NO		Bistable Y
6161600295	F1-U1Y UN	1NC / 1NO		Bistable Y, Prot. shroud UN
Two pedal foot switch F2				
Article number	Designation	Switching contacts		Special feature
		Pedal 1 (l.)	Pedal 2 (r.)	
6162840655	F2-SU1Y/SU2Z UN	1NC / 1NO	2NC / 2NO	Bistable Y (Pedal 1), Prot. shroud UN
6062610018	F2-U1Y/U1Y UN	1NC / 1NO	1NC / 1NO	Bistable Y (Pedal 1+2), Prot. shroud UN
6062610047	F2-U1Y/U1Z UN	1NC / 1NO	1NC / 1NO	Bistable Y (Pedal 1), Prot. shroud UN